

JX4	Open 1-2 2-3	Regular CPU Intel SL-enhanced CPU Cyrix CPU, AMD
JC8	Open Short	For Cyrix CPU Other CPU

Table 2-1. Jumper Settings for CPU Selector

JUMPER	PIN DEFINITION	
J1	I/O Channel Ready Select	
	Short	Adaptec ISA Master 1542B/C SCSI card only (Transfer rate ≥ 5.7 MB/s)
	Open	Default (Transfer rate < 5.7 MB/s)
J7	Password Clear	
	Short	Clear password
	Open	(default)
J4	HDD_BALE	
	Short	Enable
	Open	Disable (default)
J5	HDD_IOCHRDY	
	Short	Enable
	Open	Disable (default)
J9	1-2	(factory default)
JD1, JD2	HDD Speed Select (PDC 20230 Only)	
	IDE Type	JD1 JD2
	Fast	1-2 1-2
	Medium	2-3 1-2
	Normal	2-3 2-3 (default)
JD3	Local IDE Select	
	1-2	Disable
	2-3	Enable (default)
JN6	NS87312 I/O Port Address Select	
	1-2	Index port = 26Eh, data port = 26Fh (default)
	2-3	Index port = 398h, data port = 399h
JN7, JN8	Printer Port Direction Select	
	Direction	JN7 JN8
	Output only	1-2 2-3 (default)
	Input only	1-2 1-2
	Bi-directional	2-3 1-2, 2-3

Table 2-2. Jumper Definitions