

Service Note: OMNIBOOK_2100-02



General Information

Service note number:	OMNIBOOK_2100-02
Short description:	OmniBook 2100 Display Hinge Covers
Supersedes:	-

Administrative Information

Service note objective:	Modification recommended
Recommended action:	Upon agreeable time
Originating entity:	0264
Expiration date:	22-jul-2000
Service type:	HP location
No of labor hours paid by div:	0.100
Cost of parts:	Paid by division
Cost of travel:	Not applicable
Service inventory:	Scrap
Used Parts:	Scrap

Parts required:

Model number	Starting serial number	Ending serial number	Part number	Quantity	Description
OMNIBOOK_2100	TW00000000	TW822XXXXX	F1580-60953	1	Cover Hinge (with clip)

Detailed Service Note Content

Service Note Number(s):

OmniBook 2100-02	F1580W-02	F1580N-02	F1580WT-01
F1580NT-01	F1581W-02	F1581N-02	F1581WT-01
F1581NT-01	F1583W-02	F1583N-02	F1584W-02
F1584N-02	F1584WT-02	F1584NT-01	F1592W-02
F1592N-02	F1593W-02	F1593N-02	

HP Model and Description

HP OmniBook 2100s

To Be Performed By: Customer or HP Qualified Service Personnel

Situation

Some display hinge covers on the OmniBook 2100 may pop off the unit unexpectedly, even when the covers are snapped into place properly.

A new part, F1580-60953, includes a metal clip inside the hinge cover to prevent the problem.

Solution/Action

Check the hinge covers on OmniBook 2100s with serial numbers TW822xxxxx or lower. Replace old (F1391-60935) hinge covers without a clip with F1580-60953 (hinge cover with clip).

The instructions that follow apply to OmniBook 2100s that have display hinge covers without a clip inside and OmniBook 2100s that are missing display hinge covers.

1. Unplug the ac adapter, if present.
2. Close the display, if open.
3. Slide the two plastic hinge covers about 5mm outward, then lift them off. Use your finger or a small tool to push the hinge cover outward next to the hinge.
4. Inspect the hinge covers. If a metal clip is not visible on the underside of the hinge cover, replace the cover with part number F1580-60953 - "Cover-Hinge (with clip)."
5. Scrap old hinge covers that have no clip inside.

22 July 1998

© 1998 HEWLETT-PACKARD COMPANY

PRINTED IN U.S.A.

[Back to the index](#)